



Pallet Tracking System

NASTech, Inc.

User Guide

Version 6.0

The software described in this document is furnished under a license agreement or nondisclosure agreement. The software may be used or copied only in accordance with the terms of the agreement. It is against the law to copy the software on any medium except as specifically allowed in the license or nondisclosure agreement. No part of this manual may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying and recording for any purpose without the express written permission of *NASTech*.

NASTech, Inc. reserves the right to make changes to this document and the software described herein at any time and without notice.

Copyright © 2006 - 2008 *NASTech, Inc.* All Rights Reserved.

NASTech, Inc.
2201 Long Prairie Rd.
Suite 107-338
Flower Mound, TX 75022
(888) 9-NASTECH
www.nastechinc.com

Microsoft, MS, and MS-DOS are registered trademarks of Microsoft Corporation.

MS-SQL, and MS-Access are registered trademarks of Microsoft Corporation.

Windows is a trademark of Microsoft Corporation.

Pentium is a registered trademark of Intel Corporation.

PDF995 is a trademark of Software995 Corporation.

Table of Contents

Chapter 1	Introduction	1
	Overview	2
	System Features	3
	Events Recorded.....	3
	Statistics	3
Chapter 2	Hardware Installation.....	4
	NASTech Supplied Devices	4
	Customer Supplied Devices	4
	Install Devices	5
Chapter 3	Software Installation	1
	NASTech Supplied Software.....	1
	Customer Supplied Software.....	1
	Pre-Installation	2
	Server Installation.....	2
	System Parameters.....	3
	System.ini	3
	User Security	3
	WipTrack.ini	5
	Server SQL Setup	6
	Map Setup.....	7
	Map Creation	7
	Map Database	8
	WipTrack.ini	9
	Client Installation.....	10
	Client SQL Setup	10
	Start P-TRAQ Client.....	11
	Shortcuts.....	11
	Software Updates.....	12
	Initialization Files	14
	WipTrack.ini	14
Chapter 4	Main Screen	1
	Overview	1
	Toolbar	2
	Tree View	3
	Map View	4
Chapter 5	Markers	1
	New Marker.....	2

Table of Contents II

	Edit Marker	3
	Delete Marker	4
	Move Marker	4
	Set Room Location	4
	Zones	5
	Zone Maintenance	6
	Zone Menu	7
	Depth Maintenance	8
Chapter 6	Toolbar	1
	Map Name	1
	Availability	1
	Job Search	2
	Aging	3
	Cycle Count	4
Chapter 7	Tree View	1
	Maintenance	1
	Pallet	1
	Vendor	2
	Inquiry	3
	Job	3
	Reports	4
	Aging	4
	Creation	6
	Cycle Count	8
	Job	10
	Job With Date Range	12
	Job With Comments	14
	Location	16
	History	18
Chapter 8	Map View	1
	Geographical Level	1
	Facility Level	1
	Warehouse Level	2
	Request Cycle Count	2
	Cancel Cycle Count	2
	Zone Info	3
	Zone Level	4
	Allocate Storage	4
	Depth Maintenance	4
	Availability	5
	Allocation	5
	Bay Overload	5

Table of Contents III

Print Placards..... 6
Pallet Information 7

Chapter 9 Utilities 8

 Overview 8
 DataCopy 8
 DataLoad..... 9
 SysUpd..... 10
 User Security..... 11

Appendix A RF Controllers 1

Chapter 1 Introduction

The **NAS*Tech* Pallet Tracking** system (**P-TRAQ**) is used to track pallets both within a given facility, and throughout multiple facilities companywide. The system was designed to provide users with the real-time information needed to ensure maximum warehouse efficiency.

P-TRAQ supports all aspects of warehouse management including pallet tracking, pallet editing, warehouse transfers, and bay maintenance.

Many years of experience have gone into the design and development of this system. Simplicity and flexibility were the main criteria under which the software was developed. The system utilizes all the latest technology to provide a sound and long term solution for your business.

NAS*Tech* is committed to designing and developing the highest quality software possible and are confident that you will enjoy working with **P-TRAQ**. We look forward to working with you and wish you every success in the future.

Visit our web site at www.nastechinc.com for current news and updates.

Overview

P-TRAQ consists of three primary modules, all operating together to provide the highest level of real-time data possible without compromising the fail-safe requirements of the system.

- ◆ The **Server Module** contains the database, programs that are used to communicate with remote warehouses and hand-held devices, and system maintenance programs.
- ◆ The **Client Module** is used by Facility staff to access the tracking features and reports available by the system.
- ◆ The **RF Module** is used by forklift drivers to receive, store and maintain pallets.

System Features

- ◆ Utilizes standard PC computer hardware
- ◆ Microsoft Windows-NT/2000/XP graphical interface
- ◆ Client / Server technology
- ◆ RF data collection interface

Events Recorded

- ◆ Pallet Created
- ◆ Pallet Received
- ◆ Location Stored
- ◆ Pallet Consumed

Statistics

- ◆ Date Created
- ◆ Pallet Count
- ◆ Pallet Location

Chapter 2 Hardware Installation

Hardware components necessary for data acquisition are provided and vary depending on the actual configuration and the features to be implemented.

NASTech Supplied Devices

NASTech is responsible for providing the following hardware devices when applicable:

- ◆ None at this time.

Customer Supplied Devices

P-TRAQ utilizes standard PC hardware. The customer is responsible for providing the following hardware devices:

- ◆ **Server computer**
 - ◆ Windows NT, Windows 2000, or Windows XP.
 - ◆ At Least a 450 MHz CPU, 40GB HD, 128MB RAM.
 - ◆ SVGA Video Card, Network Interface Card.
 - ◆ CD-ROM Drive.
 - ◆ Serial Port.
 - ◆ Data Back-Up device.
- ◆ **Client Computers:**
 - ◆ Windows NT, Windows 2000, or Windows XP.
 - ◆ At Least a 450 MHz CPU, 40GB HD, 128MB RAM.
 - ◆ SVGA Video Card, Network Interface Card.
 - ◆ CD-ROM Drive.
 - ◆ Printer (Optional).
- ◆ **RF Terminals:**
 - ◆ VT100 Emulation compatibility.
 - ◆ WI-FI enabled.
 - ◆ Windows CE Operating system.

Install Devices

Please refer to the manufacturer's documentation for installation procedures for the following devices.

- ◆ Install the serial port card if not currently available.
- ◆ Install the network interface card if not currently available.
- ◆ Install the Laser Printer and software drivers.
- ◆ Connect the RF Controller to the network.
- ◆ Assign an IP Address on the network for the controller.

Chapter 3 Software Installation

NASTech Supplied Software

NASTech is responsible for providing the following software:

- ◆ PTRAQ_Server.exe.
- ◆ PTRAQ_Client.exe.

Customer Supplied Software

The customer is responsible for providing the following software:

- ◆ **Server computer**
 - ◆ Windows NT, Windows 2000, or Windows XP.
 - ◆ Microsoft Access.
 - ◆ Microsoft SQL Server. (Optional)
- ◆ **Client Computers:**
 - ◆ Windows NT, Windows 2000, or Windows XP.

Pre-Installation

The P-TRAQ Server and Client programs are to be installed on the server and client computers as described in this chapter.

The system is installed onto the Server and Client computers using custom installation programs. The installation programs should be copied to the file server to simplify the installation for multiple client computers.

Please follow the installation procedures as written and do not proceed until all prior steps have been completed successfully.

The P-TRAQ directory on the file server into which the system is installed must have read/write access from each of the client computers.

NASTech personnel will provide custom map images for your facility. Please ensure that you have these prior to installation.

Server Installation

- ◆ Create a **C:\PTRAQ** directory and a **C:\PTRAQ\Install** directory on the PTRAQ server.
- ◆ Download the installation programs from the following links:
- ◆ http://www.nastechinc.com/SUPPORT/PTRAQSupport/Install/PTRAQ_Server.exe
- ◆ http://www.nastechinc.com/SUPPORT/PTRAQSupport/Install/PTRAQ_Client.exe
- ◆ Save the downloaded installation programs to the **C:\PTRAQ\Install** directory.
- ◆ Execute **PTRAQ_Server.exe** and follow the directions on the screen to set up **P-TRAQ**.
- ◆ Note: After Installation, you may be prompted to restart the server as various DLL and OCX files may need to be registered in Windows. You may continue the installation and schedule this restart at a more convenient time if necessary.
- ◆ Create a directory with your company name into the **C:\PTRAQ\Shared** directory. (IE... **C:\PTRAQ\Shared\MyCompany**)
- ◆ Copy the Map image files sent to you by NASTech personnel to the **C:\PTRAQ\Shared\MyCompany** directory.

System Parameters

System.ini

Open the “**System.ini**” file located in the **PTRAQ\Shared** directory. If you have changed the default location of the PTRAQ directory on the server, you must change the Local and Network base path’s in this file as in the following:

- Application = "P-TRAQ"
- Init Path = "Init"
- Local Base Path = "***YourDrive:\YourDirectory\PTRAQ***"
- Network Base Path = "***YourDrive:\YourDirectory\PTRAQ***"

User Security

WIP_Security.ini

Open the “**WIP_Security.ini**” file located in the **PTRAQ\Shared\Init** directory. Verify that the company ID, division and valid systems are correct (“W” is for Wip, which is the default):

- [Constants]
- CompanyID = 1
- Division = "01"
- ValidMenus = "W"

Run **WIP_Security.exe** from the **PTRAQ/Shared** directory. For a full description of this program see the Utilities section of this document.



3 - 4 Chapter 3 Software Installation

All P-TRAQ client users will require set-up in this program to define their security level, and this can be done at any time prior to them accessing the program. The user who will be doing the initial set-up of the warehouses and racks should be entered into this program at this time and will require a security level of super user. Enter the user's **Windows User ID**, select "**Super User**" from the drop-down list provided, and click the **Save** button.

WipTrack.ini

There are some basic system parameters that need to be set up on the server at this time.

Open **WipTrack.ini** in the **PTRAQ\Shared\Init** directory and edit the following parameters as described in the following:

(Additional parameters may be edited in the file at a later time. These parameters are described in the Initialization File section of this guide.)

Parameter	Default	Description
Company Name		The name of your company which will appear on the top of Facility level maps and on system reports. Example: <code>CompanyName = "ABC Printing"</code>
Company	1	Internal Company number. Example: <code>Company = 1</code>
Division	1	The division number. Used when there are multiple divisions in your company. Example: <code>Division = 1</code>
Loc Format		The format for rack locations at your facility. Example: <code>Loc Format = "WWZ-BBB-L"</code> W – warehouse, Z – zone (rack), B – Bay (across), L – Level (up)
Bay Type	Numeric	Sets the horizontal counting method for rack locations as numeric or alphabetic. Example: <code>Bay Type = Numeric</code>
Level Type	Alpha	Sets the vertical counting method for rack levels as numeric or alphabetic. Example: <code>Bay Type = Alphabetic</code>

Server SQL Setup

- ◆ Install Microsoft SQL Server on P-TRAQ Server.
- ◆ Execute “Start...Programs...Microsoft SQL Server...Query Analyzer”.
- ◆ Open “PTRAQ\Shared\Database\PTRAQ.SQL”.
- ◆ Execute the SQL script to create **PTRAQ** database(s).
- ◆ Set permissions for P-TRAQ client computers.

Map Setup

Map Creation

The P-TRAQ system contains a host of geographical maps including a world map, all of the continents, and some countries. Prior to installation, NASTech personnel will provide the geographical maps where all of your facilities are located.

NASTech personnel will also provide maps of your actual facilities once the required floor plans or blueprints have been made available. This will also be done prior to installation.

Physical changes made to any facility must also be reflected in new images, and new Warehouse Level Map images must also be made available when applicable.

NASTech personnel will assist with map images as per the maintenance agreement.

To add or change maps locally, use an image editor that can export images in Enhanced Metafile (.emf) format.

Facility Level and Warehouse Level maps must be drawn to scale. As an example, for a facility measuring 1000 feet by 1000 feet, the exported file's properties should be 1000 pixels wide by 1000 pixels high.

3 - 8 Chapter 3 Software Installation

Map Database


Before viewing your facility with P-TRAQ, you **MUST** add the associated map image(s) to the Map Database. The map database can be edited using Microsoft Access or Microsoft SQL.

With MS Access, map entries are located in the **Map Def** table of the **PTRAQ.mdb** database located on the server in the **C:\PTRAQ\Shared\Database** directory.

With SQL, map entries are located in the **Map Def** table of the **PTRAQ** database located on the SQL server.

Before adding the maps to the database, designate a map code to describe all of the warehouses in your plant. For example, “Warehouse 1” may be referred to as WH1.

The following example shows the map hierarchy of a facility located in New York City:



Company	Division	MapType	MapParent	MapCode	MapImage	MapWidth	MapHeight
	1 04	MAP	USA	USA	Maps\NORTHAMERICA\USA\USA.emf	963	479
	1 04	MAP	USA	NY	Maps\NORTHAMERICA\USA\NEWYORK\NewYork.emf	961	752
	1 04	WHS	NY	NYC	Maps\NORTHAMERICA\USA\NEWYORK\NEWYORKCITY\NYC.emf	960	879
	1 04	WHS	NYC	CN	COMPANYNAME\FacilityName.emf	11736	10136
	1 04	WHS	CN	S1	COMPANYNAME\FacilityName-WH1.emf	4829	1827
	1 04	WHS	CN	S9	COMPANYNAME\FacilityName-WH2.emf	4829	1827
	1 04	WHS	CN	S2	COMPANYNAME\FacilityName-WH2.emf	3056	1827
	1 04	WHS	CN	F1	COMPANYNAME\FacilityName-WH3.emf	2304	1282
	1 04	WHS	CN	F2	COMPANYNAME\FacilityName-WH4.emf	2252	1282

When adding a Facility Level or Warehouse Level map to the table, add “WHS” as the MapType, add the city or state where the facility is located as the MapParent, add the distinguishable code for the map, add the path to the actual image in the MapImage field, and add the MapWidth and MapHeight in pixels of the actual image.

NASTech personnel will provide the MapWidth and MapHeight entries on any maps provided by us.

Once the map has been added to the database, you may link to it when adding Markers as described on the Markers section of this guide.

WipTrack.ini

Before viewing your facility with P-TRAQ, you **MUST** add the associated map image(s) to the **WipTrack.ini** file located in the **PTRAQ\Shared\Init** directory on the server.

This file can be edited with a typical text editor such as Microsoft Windows Notepad as in the following example:

The following example shows the map hierarchy of a facility located in Los Angeles California:

```
Node Name = "Map View"  
Node Name = "~USA", "MAP", "USA"  
Node Name = "~~California", "MAP", "CA"  
Node Name = "~~~Los Angeles Printing", "MAP", "SDP"  
Node Name = "~~~~WH #1 (WH1)", "WHS", "WH1"  
Node Name = "~~~~WH #2 (WH2)", "WHS", "WH2"
```

Client Installation

- ◆ Execute **PTRAQ_Client.exe** from the **PTRAQ\Install** directory on the file server.
- ◆ Follow the directions on the screen to set up **P-TRAQ**. Install the software in the **C:\Program Files** directory.
- ◆ Open the "**System.ini**" file located in the **C:\Program Files\PTRAQ** directory. Edit and save the file as follows:
 - Init Path = "Init"
 - Local Base Path = "C:\Program Files\PTRAQ"
 - Network Base Path = "*YourServer/IPaddress*\PTRAQ"
 - DBTYPE = "SQL"

Client SQL Setup

- ◆ Create ODBC Data Source Name (DSN) called **PTRAQ** for new PTRAQ SQL Server database.
 - Start - Settings - Control Panel - Administrative Tools - Data Sources - ODBC
 - Click "**Add**". Select **SQL Server**, Click "**Finish**".
 - Name database (PTRAQ), and select the PTRAQ Server.
 - NT or SQL authentication? It is recommended that NT authentication is used. If so, the NT password setup on the computer will allow access to the SQL database.
 - NT or SQL authentication? If SQL authentication is used, the following lines of code **MUST** be added to the **C:/ProgramFiles/PTRAQ-Client/System.ini** file:
 - DB Name = PTRAQ
 - Database = PTRAQ
 - User Name = *your computer's User Name*
 - Password = *your SQL Password*
 - Click "**Change Default DB to**", Select PTRAQ Database, Click **Next**.
 - Test the connection and click OK.

Start P-TRAQ Client

- ◆ Go to **Start Menu** → **Programs** → **PTRAQ-Client Module** → **SysUpd**, right-click the **SysUpd** icon and select **Properties**. Edit and save the shortcut as follows:
 - Target: *YourServer/PTRAQ/Shared/SysUpd.exe*
 - Start In: *C:/Program Files/PTRAQ/*
- ◆ Run **Start Menu** → **Programs** → **PTRAQ-Client Module** → **SysUpd** and click the **Update** button.

Shortcuts

- ◆ You should also create a folder on the desktop called **P-TRAQ**. Add the following to the folder:
 - Shortcut to **C:\Program Files\PTRAQ**
 - Shortcut to our **Website** which is www.nastechinc.com
 - Shortcut to a new file called "**Password.txt**" (Create this file, add the following text, and save):
 - Username = *yourcompanyname* (all lowercase)
 - Password = support
- ◆ Let the users know that our **UserGuide** is available for viewing online. If you open it online versus downloading it, the MS Word document contains hyperlinks in the Table of Contents.

Software Updates

Customers will be notified by email when software updates are available for download. It is recommended that you update the software within a reasonable time frame as to avoid redundant support issues.

The [P-TRAQ support page](#) on our website always contains the latest updates, as well as version specific information relating to each updated program. Check our support pages periodically for additional information.

Manual Updates

Manual Updates to the software are handled as follows:

- Delete all files from the **C:\PTRAQ\Shared\SoftwareUpdate** directory on the server.
- Download SoftUpd.zip from the following link:
- <http://www.nastechinc.com/SoftwareRelease/PTRAQ/SoftUpd.zip>
- Save the .zip file to the **C:\TRAQ\Shared\SoftwareUpdate** directory on the server.
- Unzip the downloaded file and save its contents to the **C:\PTRAQ\Shared\SoftwareUpdate** directory on the server.
- Run **Install.bat** from the **C:\PTRAQ\Shared\SoftwareUpdate** directory on the server. Click the **Continue** button and wait for completion.

1. Run **DataComp.exe** from the **C:\PTRAQ\Shared** directory on the server, and click the **Continue** button. If database field mismatches are present...
 - *Run the included **Update.SQL** script in **SQL Query Analyzer**, and run **DataCopy.exe** from the **Start Menu** at EACH client computer.*
2. **SysUpd.exe**: The updated files may be transferred and installed manually to each client computer by running the **SysUpd.exe** program at the associated computer.

Initialization Files

The following describes the initialization files in detail in cases where modifications are required. In each file, the parameters are divided into multiple sections as outlined. Upper and lower case may be used as desired with additional spacing for readability since all characters are converted to lower case and imbedded spaces are discarded prior to evaluation.

WipTrack.ini

[Constants]

Parameter	Default	Description	
Company Name		The name of your company which will appear on the top of Facility level maps and on system reports. Example: CompanyName = "ABC Printing"	
Company	1	Internal Company number. Example: Company = 1	
Division	1	The division number. Used when there are multiple divisions in your company. Example: Division = 1	
Loc Format		The format for rack locations at your facility. Example: Loc Format = "WWZ-BBB-L" W – warehouse, Z – zone (rack), B – Bay (across), L – Level (up)	
Bay Type	Numeric	Sets the horizontal counting method for rack locations as numeric or alphabetic. Example: Bay Type = Numeric	
Level Type	Alphabetic	Sets the vertical counting method for rack levels as numeric or alphabetic. Example: Bay Type = Alphabetic	
Menu Width	3600	Sets the default tree view menu screen width. Example: Menu Width = 3600	**
Menu Hide	No	Defaults the tree view menu to the hidden position. Example: Menu Hide = Yes	**
Rack Color Full	Dark Green	Sets the color to be used for full bays. Example: Rack Color Full = RGB(0,98,17)	**
Rack Color Partial	Light Green	Sets the color to be used for partially full bays. Example: Rack Color Partial = RGB(0,157,28)	**
Job Color Full	Blue	Sets the color to be used for bays containing the job as searched.	

Parameter	Default	Description
		Example: Job Color Full = RGB(0,0,160)
Job Color Partial	Blue	Sets the color to be used for bays containing the job as searched. Example: Job Color Partial = RGB(0,0,200)
Aging Color Full	Dark Brown	Sets the color to be used for bays containing dated pallets as searched. Example: Aging Color Full = RGB(118,76,36)
Aging Color Partial	Light Brown	Sets the color to be used for bays containing dated pallets as searched. Example: AgingColorPartial=RGB(187,166,146)

3 - 16 Chapter 3 Software Installation

Database

This section is used to define the path to the database, and to define the IP Address and IP Post of the server PC.

Parameter	Default	Description
Data Path		Specifies the full path of the P-TRAQ database. IE: DataPath = X:\PTRAQ\Shared\Database
Base IP Address		Specifies the network IP address of the server PC. IE: BaseIpAddress = 000.000.000.000
Base IP Port		Specifies the port number to be used for communication with the server PC. IE: BaseIPPort= 23

Company Tree

This section is used to define the nodes on the tree view. Included are the main nodes as defined by the system, and a hierarchy of maps to define warehouse locations within your company. The “~” denotes the level in the tree.

Parameter	Default	Description
Node Name	Maintenance	Main Maintenance node
Node Name	~Pallet	
Node Name	~Vendor	
Node Name	Inquiry	Main Inquiry node
Node Name	~Job	
Node Name	Reports	
Node Name	~Aging	
Node Name	~Creation	
Node Name	~Cycle Count	
Node Name	~Discard	
Node Name	~Job	
Node Name	~Job With Date Range	

3 - 17 Chapter 3 Software Installation

Parameter	Default	Description
Node Name	~Job With Comments Only	
Node Name	~Location	
Node Name	~Pallet History	
Node Name	Purge	Main Purge node
Node Name	~Inventory Purge	
Node Name	~Pallet Purge	
Node Name	Map View	Main Map node
Node Name	~World	
Node Name	~~North America	
Node Name	~~~USA	
Node Name	~~~~Wisconsin	
Node Name	~~~~~Facility1	
Node Name	~~~~~~Warehouse1	
Node Name	~~~~~~Warehouse2	

Edit

This section is used to alter the data edit criteria of the system. The entries in this section consist of a Field Name followed by an equal sign, followed by a series of keywords and their associated values. The keyword and values sets are separated by semicolons. The use of spaces is optional.

Keyword	Default	Description
type	1	0 = Display Only 1 = Alphabetic or Numeric 2 = Alphabetic 3 = Numeric (no decimal) 4 = Numeric (decimal allowed) 5 = Date 6 = Time 8 = Yes/No
minl	1	Minimum number of characters which may be entered. Example: minl=3

3 - 18 Chapter 3 Software Installation

Keyword	Default	Description
maxl		Maximum number of characters which may be entered. Example: maxl=8
optreq	R	“R” = required, entry is required. “O” = optional, entry may be left blank. When left blank, the value defined by the “default” is inserted as if it were keyed by the operator. Example: optreq=0
default		Default value to be used if user leaves the entry blank. If the data is optional this entry is displayed automatically. Example: Default=1
format		Formats the parameter to allow for leading zeros, or the elimination of leading zeros. Example: format=00 (adds a leading zero to single digit number) Example: format=#0 (removes leading zero from 2 digit number)
minv		Minimum numeric value which may be entered. Example: minv=1
maxv		Maximum numeric value which may be entered. Example: maxv=999
scaler	2	Maximum number of digits which may follow decimal point. Example: scaler=2
pattern		A sequence of element size, type and constants. Multiple patterns are separated by commas. For example, a telephone number pattern might be: pattern=3N-4N, 3N-3N-4N
level	1	0 = field may not be changed. 1 = field may only be changed when P-TRAQ is in STOP mode. 2 = field may be changed at any time. (Check with NASTech before using this feature).
valdat		Used to define the valid entries for a given parameter. Valid entries are separated by commas. Example: valdat=a,b,c,d
Verify	No	Verifies the validity of the employee against the Employee table. Example: verify=yes


The following describes the default edit criteria for each entry field. The last group defines the edit criteria for entry fields on the remote terminals. To alter the edit criteria, place the command in the **Edit** section of the **Pressman.ini** file. To force a 7 digit numeric job number, enter the following command.

Parameter	Default Edit Criteria
Zone Depth	"type=20; minl=8; maxl=8"

Chapter 4 Main Screen

Overview

To run the system, double-click the desktop **P-TRAQ** icon.



This is the main screen. The main screen contains a Toolbar, the Tree View and the Map View.

Each section of the screen is defined on the following pages of this chapter.

Toolbar

The Toolbar section of the screen contains the current map name, and buttons to control the various functions of the system.




Details

Map Name	As in the above example, "USA" is the name of the currently viewed map.
Up Arrow	Used to ascend up a level to the parent map if applicable.
Left Arrow	Used to go back to the previous map.
Availability	Turns on Availability mode (Default Mode)
Job Search	Turns on Job Search Mode.
Aging	Turns on Aging Mode.
Cycle Count	Turns on Cycle Count Mode.

Tree View

The Tree View is used to select the Maintenance, Inquiry, and Report functions of the system, and to view a hierarchy of available maps.




Details

Maintenance	Used to access the Pallet and Vendor Maintenance screens.
Inquiry	Used to access the Job inquiry functions.
Reports	Used to access the Reports.
Map View	Used to display the map hierarchy and to change the currently displayed map.
<<<, >>>	Arrows are used to show or hide the Tree View.

Map View

The Map View displays the currently selected map.



Details

- | | |
|---------------------------|---|
| <p>Geographical Level</p> | <p>Geographical Level Maps are used to display warehouse locations when multiple warehouses are available. Markers as shown in Fig 4.4a are used to link to subsequent geographical maps, or directly to Facility level maps.</p> |
| <p>Facility Level</p> | <p>Facility Level Maps as shown in Fig 4.4b are drawn to scale and are displayed from top view. These maps contain both markers used to zoom in to warehouse levels, and clickable zones used to zoom in directly to a given zone.</p> |
| <p>Warehouse Level</p> | <p>Warehouse Level Maps as shown in Fig 4.4c, also displayed from top view, contain clickable zones used to zoom in to the zone level maps.</p> |
| <p>Zone Level</p> | <p>Zone Level Maps as shown in Fig 4.4d are displayed from left to right view and represent the view a person would have if they were standing in front of the zone and facing the zone.</p> |

Chapter 5 Markers

This chapter explains the procedures used to set up markers, and to draw zone locations within a given warehouse. Also included are procedures to draw rooms when warehouse additions or any other physical changes to your facility have been completed.


Markers (as shown in Fig 5.3a) are used to link to subsequent maps when viewing Geographical Level or Facility Level Maps. They can also be used to name a given city or an area of your facility without linking.

Markers are saved to the Map Marker table of the PTRAQ.mdb database.




Fig 5.3a

When viewing a Geographical or Facility Level Map, right-click on the map to access the Marker dropdown menu.



New Marker

Selecting the New Marker menu option opens the **Map Marker Maintenance** dialog box.



The dialog box is titled "Map Marker Maintenance". It is divided into two main sections: "Link" and "Marker".


- Link Section:** Contains a text input field labeled "Desc" and a dropdown menu labeled "Link" with "None" selected.
- Marker Section:** Contains six dropdown menus:
 - Mark:** Circle
 - Style:** Italic
 - Color:** Light
 - Size:** 10
 - Pos:** Left
 - Color:** Dark

At the bottom of the dialog box are three buttons: "OK", "Cancel", and "Apply".

Desc	The name of the Marker as it will be displayed on the screen.
Link	Dropdown box to link the Marker to the map from the database.
Mark	Dropdown used to select the shape of the Marker.
Color	The Color of the Marker.
Pos	The position of the Marker in relation to the Marker Description (center, left or right).
Style	The style of the Marker Description font (regular, italic, bold or bold italic).
Size	The size of the Marker Description font size.
Color	The color of the Marker Description font color.

Edit Marker

Selecting the Edit Marker menu option opens the **Map Marker Maintenance** dialog box. This menu option is only available upon right-clicking an existing Marker.



The image shows a dialog box titled "Map Marker Maintenance". It is divided into two sections: "Link" and "Marker".

- Link Section:** Contains a text input field labeled "Desc" and a dropdown menu labeled "Link" with "None" selected.
- Marker Section:** Contains several dropdown menus:
 - Mark:** Set to "Circle".
 - Style:** Set to "Italic".
 - Color:** Set to "Light".
 - Size:** Set to "10".
 - Pos:** Set to "Left".
 - Color:** Set to "Dark".

At the bottom of the dialog box are three buttons: "OK", "Cancel", and "Apply".

Desc	The name of the Marker as it will be displayed on the screen.
Link	Dropdown box to link the Marker to the map from the database.
Mark	Dropdown used to select the shape of the Marker.
Color	The Color of the Marker.
Pos	The position of the Marker in relation to the Marker Description (center, left or right).
Style	The style of the Marker Description font (regular, italic, bold or bold italic).
Size	The size of the Marker Description font size.
Color	The color of the Marker Description font color.

Delete Marker

Selecting the Delete Marker menu option deletes the selected Marker. This menu option is only available upon clicking an existing Marker. A dialog box will be presented to verify the deletion.

Move Marker

To move a marker, hold down the CTRL key on the keyboard, then click and drag the Marker to its new location.

Set Room Location

The Set Room Location menu option is used to set the reference point of a given warehouse on the Facility Map.

This option is only available while viewing a Facility Level Map, and is only available upon right-clicking a Marker. After selecting this option, click in the top left-hand corner of the Warehouse on the associated Facility Map.

This should be performed prior to drawing any zones in the warehouse. If this is performed after zones have been added, the zones on the screen will be moved in relation to the new reference point.

Zones

Zones are the graphical representation of the actual storage racks for the pallets in a warehouse. When zones are displayed within the warehouse, the assumption is that the user is looking at the zone from the top.

Zones may only be created and edited while viewing a Warehouse Level Map only.




Fig 5.7a

To create a new Zone click on an area that does not currently contain a zone, hold the mouse button down, and drag the cursor to draw an outline of the new Zone as shown in **Fig 5.7b**.

The thick black lines surrounding $\frac{3}{4}$ of the existing zones as shown in **Fig 5.7b** are used to represent the rear and sides of the associated zone. By default, Zones will be drawn from the first rear bay extending outward left to right as if facing the zone.




Fig 5.7b

Zone Maintenance


Once you release the mouse button the Zone Maintenance dialog box is displayed.



Zone ID	The Zone ID number.
Type	Dropdown list used to designate the zone as a Consumer, Shredder, Storage, or Vendor location. The consumer and shredder locations zero the quantity on the pallet. An example of a consumer location would be the bindery.
X-Position	The horizontal position in the warehouse of the rear first bay.
Y-Position	The vertical position in the warehouse of the rear first bay.
Bays	The number of horizontal bays.
Levels	The number of vertical levels.
Depth	The number of pallets that can be stored in the bay.
Rotation	Rotate the zone so it can represent the correct orientation within the warehouse.
Bay Width	The horizontal size of the bay in inches.
Bay Depth	The vertical size of the bay in inches.
Alias	The alias is another name for the zone. This field is optional and gives you the ability to use a more familiar name for a special zone. Zones with an alias can only have one bay (horizontal) and one level (vertical).
Accept	Creates the zone once all required fields have been updated.
Cancel	Cancels the transaction.

Zone Menu


Right-Clicking an existing Zone on a Warehouse Level Map opens the Zone Menu.



Duplicate	Makes a copy of the selected Zone and opens the Zone Maintenance dialog box to make the necessary changes to the new Zone.
Edit	Opens the Zone Maintenance dialog box to allow changes to be made to the selected Zone.
Rotate Clockwise	Rotates the selected zone 90 degrees clockwise.
Rotate 180	Rotates the selected zone 180 degrees.
Rotate Counter	Rotates the selected zone 90 degrees counter-clockwise.
Delete	Deletes the selected zone. A dialog box will be presented to confirm the deletion.
Request Cycle Count	Used to create a Cycle Count for the zone with today's date.
Cancel Cycle Count	Used to delete the Cycle Count that already exists for this zone.

Depth Maintenance

To change the depth of an existing zone location, click the bay location on a Zone Level Map, and select Depth Maintenance from the menu.



Selecting the Depth Maintenance option opens the Depth Maintenance Screen.



Select the Depth of the Zone from the dropdown list or enter an amount up to 99. If the zone can hold an unlimited amount, you can enter “-1” or choose “Unlimited” from the dropdown box. If the location is set to an unlimited depth, it will never show up as having an overflow condition. Click the OK button to complete.

Chapter 6 Toolbar

The Toolbar section of the screen contains the current map name, and buttons to control the various functions of the system.



Map Name

The Map Name section displays the name of the currently viewed map. The Up Arrow is used to ascend up a level to the parent map if applicable.

Availability

The Availability button turns on Availability mode. When viewing Facility Level, Warehouse Level, or Zone Level Maps, the bays are colored using green and white to provide a graphical representation of bay availability.




Fig 6.1a

As shown in **Fig 6.1a**, bays colored in **Dark Green** represent full bays.

Bays colored in a **Light Green** color represent partially full bays.

Bays shown in white represent empty bays.

Job Search

The Job Search button turns on Job Search mode and expands the Job Toolbar to allow entry of the customer, job and/or part number that you want to search for.



After entering a Customer ID or a Job Number (and/or optional Part ID), the user can start the associated search by clicking the green arrow button. The red X button is used to cancel the search.

When viewing Facility Level, Warehouse Level, or Zone Level Maps, the bays are colored using blue and white to provide a graphical representation of the location of pallets for the associated job.




Fig 6.2a

As shown in **Fig 6.2a**, bays colored in **Blue** represent those bays that contain pallets for the associated job.

Aging

The Aging button turns on Aging mode and expands the Aging Toolbar to allow entry of the associated search parameters.



After selecting the search basis (Creation Date or Last Activity Date), and the age of the pallets, the user can start the associated search by clicking the green arrow button. The red X button is used to cancel the search.

When viewing Facility Level, Warehouse Level, or Zone Level Maps, the bays are colored using brown and white to provide a graphical representation of the location of the associated pallets.




Fig 6.3a


As shown in **Fig 6.3a**, bays colored in **Dark Brown** represent bays full of pallets that fit the search criterion.

Bays colored in a **Light Brown** color represent bays partially full of pallets that fit the search criterion.

Bays shown in white represent those bays that do not contain pallets that fit the search criterion.

Cycle Count

The Cycle Count Button turns on Cycle Count Mode.



After clicking the Cycle Count Button the user can start the associated search by clicking the green arrow button. The red X button is used to cancel the search.

When viewing Facility Level, Warehouse Level, or Zone Level Maps, the bays are colored using red and white to provide a graphical representation of the bays that are marked for a cycle count.




Fig 6.3a

As shown in Fig 6.3a, bays colored in **Dark Red** represent bays that are marked for a cycle count.

Bays colored in a **Light Red** color represent bays for which the cycle count procedure has been partially completed.

Bays colored in a **White** color represent bays for which the cycle count procedure has been fully completed.

Chapter 7 Tree View

Maintenance

The Maintenance Tree View Option allows you to add new or modify existing Pallets and Vendors.


-  Maintenance
-  Pallet
-  Vendor

Pallet

Selecting the Pallet menu option opens the Pallet Maintenance screen.

When viewing an existing Pallet in the Zone Map, selecting this option will automatically fill in all fields from the database for subsequent editing. Otherwise, all fields will be blank.

If you enter an existing Pallet ID, the system will automatically fill in all fields for the associated Pallet from the database for editing. You may also enter a job number which will present a list of all Pallets for the associated Job for selection.



The screenshot shows the 'Pallet Maintenance' window with the following fields and controls:

- Pallet ID:
- Job ID:
- Cust ID:
- Part ID:
- Skid #:
- Sequence #:
- Quantity: Qty Per Bundle:
- Location:
- Vendor ID:
- Description:
- Discard?:
- Hold?:
- Buttons: Save, Cancel, Print

Hold?

Checking this field will set the status of the pallet to "on hold". Pallets marked as "on hold" will not be identified to the forklift driver as available.

Save

Saves the associated record.

Cancel

Cancels the addition or modification.

Print


Prints the Pallet information.

7 - 2 Chapter 7 Tree View

Vendor

Selecting the Vendor menu option opens the Vendor Maintenance screen.

If you enter an existing Vendor ID, the system will automatically fill in all fields for the associated Vendor from the database for editing.



The screenshot shows a window titled "Vendor Maintenance". It contains two input fields: "Vendor ID" and "Name". Below the input fields are two buttons: "File" and "Cancel".

File

Saves the associated record.

Cancel

Cancel the addition or modification.

Inquiry

The Inquiry Tree View Option allows you to perform a Job Inquiry search.



Job

Selecting the Job menu option expands the Job Heading to allow entry of the job number you wish to search for.



After entering a Customer ID, Job Number or optional Part ID, clicking the green arrow button starts the associated search. The red X button is used to cancel the inquiry.

Reports

The Inquiry Tree View Option allows you to perform a Job Inquiry search.

- Reports
 - Aging
 - Creation
 - Cycle Count
 - Discard
 - Job
 - Job With Date Range
 - Job with Comments Only
 - Location
 - Pallet History

Aging

Selecting the Aging menu option opens the WIP Inventory Aging dialog box.



Age Basis

Used to search for pallets by Creation date, or by the Last Transaction date.

Days Old

Used to select the number of days to search.

OK

Used to generate the report.

Cancel

Used to cancel the report.

WIP Inventory Aging

30 Days old, based on Creation date

Date	Job #	Customer	Pallet #	Part ID	Type	Quantity	Location	Description
------	-------	----------	----------	---------	------	----------	----------	-------------

Date	The Creation date of the pallet.
Job #	The Job Number.
Customer	The Customer Name.
Pallet #	The Pallet Number.
Part ID	The Part ID Number.
Type	The Pallet Type.
Quantity	The Quantity on the pallet.
Location	The Location of the pallet.
Description	The optional Description of the pallet.

Creation

Selecting the Creation Menu option opens the WIP Inventory by Creation Date Dialog box.



The screenshot shows a dialog box titled "WIP Inventory By Creation Date". It has a standard Windows-style title bar with a close button (X) in the top right corner. The dialog contains three input fields arranged vertically on the left side, each with a corresponding text label to its left. The first field is labeled "Whse" and is currently empty. The second field is labeled "Start Date" and contains the text "07/31/07". The third field is labeled "End Date" and also contains the text "07/31/07". At the bottom of the dialog, there are two buttons: "OK" on the left and "Cancel" on the right.

Whse

The warehouse to search.

Start Date

The Starting Date of the search. Clicking in this text field brings up a calendar. The user can click on a specific date on the calendar and the date will populate this field.

End Date

The Ending Date of the search. Clicking in this text field brings up a calendar. The user can click on a specific date on the calendar and the date will populate this field.

OK

Used to generate the report.

Cancel

Used to cancel the report.


WIP Inventory By Creation Date

Date	Time	Job #	Part ID	Customer	Pallet #	Skid	Type	Quantity	Emp
------	------	-------	---------	----------	----------	------	------	----------	-----

Date	The Creation date of the pallet.
Time	The Creation Time of the pallet.
Job #	The Job Number.
Part ID	The Part ID Number.
Customer	The Customer Name.
Pallet #	The Pallet Number.
Skid	The Skid Number.
Type	The Pallet Type.
Quantity	The Quantity on the pallet.
Emp	The Employee Number.

Cycle Count

Selecting the Cycle Count Menu option opens the Cycle Count Dialog box.



The image shows a standard Windows-style dialog box titled "Cycle Count". It features a title bar with a close button (X) in the top right corner. The main area contains five input fields, each preceded by a label button: "Whse", "Begin Zone", "End Zone", "Alias", and "Empty?". The "Empty?" field is a checkbox. At the bottom of the dialog are two buttons: "OK" and "Cancel".

Whse	The warehouse to search.
Begin Zone	The Starting Zone.
End Zone	The Ending Zone of the search.
Alias	Another name for the given zone.
Empty?	Allows empty bay locations to be displayed on the report.
OK	Used to generate the report.
Cancel	Used to cancel the report.

Cycle Count

Warehouse WP Zones A through Z

Date	Time	Job #	Customer	Pallet #	Quantity	Current Location	Last Tran		
							Date	Time	Emp

Date	The Date the Cycle Count was completed.
Time	The Time the Cycle Count was completed.
Job #	The Job Number.
Customer	The Customer Name.
Pallet #	The Pallet Number.
Quantity	The Quantity on the pallet.
Location	The Location of the pallet.
Date	The Last Transaction Date of the pallet.
Time	The Last Transaction Time of the pallet.
Emp	The Employee Number who completed the last transaction.

Job

Selecting the Job Menu option opens the WIP Inventory by Job Dialog box.



Customer

The Customer Number.

Job

The Job Number.

Part

The Part Number.

OK

Used to generate the report.

Cancel

Used to cancel the report.

WIP Inventory By Job


Job 0509066

Job #	Part ID	Pallet #	Skid	Type	Location	WIP Quantity	Consumed Quantity	Date	Time	Emp	Location 2	Location 3	Description
-------	---------	----------	------	------	----------	-----------------	----------------------	------	------	-----	------------	------------	-------------

Job #	The Job Number.
Part ID	The Customer Name.
Pallet #	The Pallet Number.
Skid	The Skid Number.
Type	The Pallet Type.
Location	The Location of the job's pallet.
Pallet #	The Pallet Number.
WIP Quantity	The Quantity on the pallet.
Consumed Quant.	The Consumed Quantity.
Date	The Date the pallet was created.
Time	The Time the pallet was created.
Emp	The Employee Number who completed the last transaction.
Location 2	The second Location.
Location 3	The third Location.
Description	The optional Description of the pallet

Job With Date Range

Selecting the Job With Date Range Menu option opens the WIP Inventory by Job With Date Range Dialog box.



The screenshot shows a dialog box titled "WIP Inventory By Job with Da...". It contains the following fields and values:

Field	Value
Customer	
Job #	0509068
Part #	
Start Date	07/31/07
End Date	07/31/07

Buttons: OK, Cancel

Customer	The Customer Name.
Job #	The Job Number.
Part #	The Part Number.
Start Date	The Starting Date of the search. Clicking in this text field brings up a calendar. The user can click on a specific date on the calendar and the date will populate this field.
End Date	The Ending Date of the search. Clicking in this text field brings up a calendar. The user can click on a specific date on the calendar and the date will populate this field.
OK	Used to generate the report.
Cancel	Used to cancel the report.

WIP Inventory By Job

Job 0509066

Job #	Part ID	Pallet #	Skid	Type	Location	WIP Quantity	Consumed Quantity	Date	Time	Emp	Location 2	Location 3	Description
-------	---------	----------	------	------	----------	-----------------	----------------------	------	------	-----	------------	------------	-------------

Job #	The Job Number.
Part ID	The Customer Name.
Pallet #	The Pallet Number.
Skid	The Skid Number.
Type	The Pallet Type.
Location	The Location of the job's pallet.
Pallet #	The Pallet Number.
WIP Quantity	The Quantity on the pallet.
Consumed Quant.	The Consumed Quantity.
Date	The Date the pallet was created.
Time	The Time the pallet was created.
Emp	The Employee Number who completed the last transaction.
Location 2	The second Location.
Location 3	The third Location.
Description	The optional Description of the pallet

Job With Comments

Selecting the Job With Comments Menu option opens the WIP Inventory by Job With Comments Dialog box.



The image shows a dialog box titled "WIP Inventory By Job with Co...". It has a standard Windows-style title bar with a close button (X) in the top right corner. The dialog contains three input fields stacked vertically. The first field is labeled "Customer" and is empty. The second field is labeled "Job #" and contains the text "0509068". The third field is labeled "Part #" and is empty. Below the input fields are two buttons: "OK" on the left and "Cancel" on the right.

Customer	The Customer Name.
Job #	The Job Number.
Part #	The Part Number.
OK	Used to generate the report.
Cancel	Used to cancel the report.

WIP Inventory By Job


Job 0509066

Job #	Part ID	Pallet #	Skid	Type	Location	WIP Quantity	Consumed Quantity	Date	Time	Emp	Location 2	Location 3	Description
-------	---------	----------	------	------	----------	-----------------	----------------------	------	------	-----	------------	------------	-------------

Job #	The Job Number.
Part ID	The Customer Name.
Pallet #	The Pallet Number.
Skid	The Skid Number.
Type	The Pallet Type.
Location	The Location of the job's pallet.
Pallet #	The Pallet Number.
WIP Quantity	The Quantity on the pallet.
Consumed Quant.	The Consumed Quantity.
Date	The Date the pallet was created.
Time	The Time the pallet was created.
Emp	The Employee Number who completed the last transaction.
Location 2	The location of the pallet previous to its current location.
Location 3	The location of the pallet, previous to location 2.
Description	The optional Description of the pallet.

Location

Selecting the Location Menu option opens the WIP Inventory by Location Dialog box.



The screenshot shows a dialog box titled "WIP Inventory By Location". It has a standard Windows-style title bar with a close button (X) in the top right corner. The dialog contains four input fields arranged vertically on the left side, each with a corresponding text box on the right. The first field is labeled "Whse" and contains the text "WP". The second field is labeled "Begin Zone" and contains the text "A". The third field is labeled "End Zone" and contains the text "Z". The fourth field is labeled "Empty?" and has an unchecked checkbox next to it. At the bottom of the dialog are two buttons: "OK" on the left and "Cancel" on the right.

Whse

The Warehouse to search.

Begin Zone

The Starting Zone.

End Zone

The Ending Zone of the search.

Empty?

Allows empty bay locations to be shown on the report.

OK

Used to generate the report.

Cancel

Used to cancel the report.

WIP Inventory By Location

Warehouse WP Zones A through Z

Job #	Part ID	Pallet #	Skid	Type	Location	WIP Quantity	Last Move			Location 2	Location 3	Description
							Date	Time	Emp			

Job #	The Job Number.
Part ID	The Customer Name.
Pallet #	The Pallet Number.
Skid	The Skid Number.
Type	The Pallet Type.
Location	The Location of the job's pallet.
WIP Quantity	The Quantity on the pallet.
Consumed Quant.	The Consumed Quantity.
Date	The Date the pallet was created.
Time	The Time the pallet was created.
Emp	The Employee Number who completed the last transaction.
Location 2	The location of the pallet previous to its current location.
Location 3	The location of the pallet, previous to location 2.
Description	The optional Description of the pallet.

History

Selecting the History Menu option opens the WIP pallet History Dialog box.



Pallet ID

The Pallet ID.

OK

Used to generate the report.

Cancel

Used to cancel the report.

WIP Pallet History

Pallet ID H1534957

Job #	Part ID	Skid	Type	Date	Time	Quantity	Location	Emp	Description
-------	---------	------	------	------	------	----------	----------	-----	-------------

Job #	The Job Number.
Part ID	The Part Number.
Skid	The Skid Number.
Date	The Date the pallet was created.
Time	The Time the pallet was created.
Quantity	The Quantity on the pallet.
Location	The Location of the pallet.
Emp	The Employee Number who completed the last transaction.
Description	The optional Description of the pallet.

Chapter 8 Map View

The Map View displays the currently selected map. The following explains the procedures used to navigate the Map View.

Geographical Level

Geographical Level Maps as shown in **Fig 8.1a** are used to display warehouse locations when multiple warehouses are available. Markers are used to link to subsequent geographical maps, or directly to Facility level maps.




Fig 8.1a

Facility Level

Facility Level Maps as shown in **Fig 8.1b** are drawn to scale and are displayed from top view. These maps contain both markers used to zoom in to warehouse levels, and clickable zones used to zoom in directly to a given zone.




Fig 8.1b

Right-Clicking on a given point on a Facility Level map displays the Marker Menu as described in the Screen Setup chapter of this guide.

Warehouse Level

Warehouse Level Maps as shown in **Fig 8.2a** are also displayed from top view, contain clickable zones used to zoom in to the zone level maps.




Fig 8.2a


Procedures

Clicking and dragging from a given point on a Warehouse Level map allows a new zone to be drawn as described in the Screen Setup chapter of this guide.

Right-Clicking an existing zone opens the Zone Menu as described in the Screen Setup chapter of this guide.

Clicking an existing zone while holding the CTRL key allows an existing zone to be relocated within the warehouse (as described in the Screen Setup chapter of this guide).

Right-Clicking an area of the warehouse that does not currently contain a zone opens the Cycle Count Menu.



Request Cycle Count

The Request Warehouse Cycle Count Menu option is used to request a cycle count for the entire warehouse. Requesting a Cycle count must be done before forklift operators are asked to do a cycle count in the warehouse. The forklift operator will use the RF function called "Cycle Count" to complete the cycle count for each location in the warehouse.

Cancel Cycle Count

The Cancel Warehouse Cycle Count Menu option is used to cancel the Cycle Count request.

Zone Info

Moving the mouse over an existing column of bays expands the toolbar to display the Zone Info toolbar.

Zone ID	X-Pos	Y-Pos	Bays	Levels	Depth	Rotate	Bay	Alias
A	109'	105'	23	4	5	270	6	

Zone ID	The alphabetical Zone location.
X-Pos	The Horizontal position of the top left corner of the Zone as it relates to the warehouse.
Y-Pos	The Vertical position of the top left corner of the Zone as it relates to the warehouse.
Bays	The number of Bays wide.
Levels	The number of Bays tall.
Depth	The number pallets that can be stored in the Bay location.
Rotate	The position of the top left corner of the Zone as it relates to the upper left corner of the warehouse.
Bay	The current Bay location under the mouse.
Alias	Another name for the Bay location.

Zone Level

Zone Level Maps as shown in **Fig 8.4a** are displayed from left to right view as if standing in front of the Zone.






Fig 8.4a

Procedures

Clicking on a bay location displays the Bay Maintenance Menu.



Right Clicking on a bay location displays the Bay Info Menu.



Allocate Storage


Used to allocate storage to a certain job and part ID. When pallets are ready to be stored for the job and part ID, one of the locations allocated will display on the RF screen as a recommended storage location for the pallet. Pallets from other jobs or part ID's will not be denied storage in the location. The allocated storage location is just a recommended location in order for warehouse management to organize jobs in the warehouse.

Depth Maintenance

The Depth Maintenance menu option is used to set a new depth of the bay location. This overrides the number set for the associated Bay Location as it relates to the entire Zone. The depth can be set to zero, any number or the word, "Unlimited". Setting the depth to unlimited is used to stop the zone display from showing an overflowing location. This is useful when the amount of space in the location can not be determined or is unimportant. A pallet can be moved to a location that shows on the zone display to be overflowing but physically has space. Therefore, the depth of a location is used for informational purposes only and not as a limitation.


Availability

The Availability menu option is used to view the Zone in Availability Mode.



Allocation

The Allocation menu option is used to view the Zone in Allocation Mode.



In Availability Mode, the numbers displayed represent the number of pallets in each Bay location.

In Job Search Mode, the numbers displayed represent the number of pallets for the associated job which are stored in the associated Bay location.

In Aging Mode, the numbers displayed represent the number of pallets that fit the search criteria which are stored in the associated Bay location.

Bay Overload

When the number of pallets stored in a Bay Location in the database exceeds the maximum allowable number that can be stored in the physical location, the system will draw a yellow X through the Bay Location, as shown below.




Print Placards

The Print Placards menu option displays the Print Placards Screen. Placards are used to identify Bay Locations. The Barcodes should be adhered to the actual Bay Location for scanning with the RF controller.



Warehouse	The Warehouse.
Zone	The Zone ID.
Number Up	The number of copies to print.
OK	Prints the Placards.
Cancel	Cancels the request.

Once the required parameters have been entered, clicking the OK button prints the placards in PDF format.



Pallet Information

The Pallet Information menu option displays the Pallet Information Screen.

The left side of the screen lists all the pallets stored in the associated Bay location.

The right side of the screen displays the pallet information of the currently selected pallet.

The screenshot shows a window titled "Pallet Information". On the left is a table with two columns: "PalletID" and "Description". The first row is selected and highlighted in yellow.

PalletID	Description
B0470666	SAKS, INC.
D0474296	TARGET STORES INC
G1290758	SAKS, INC.

On the right side, there are several input fields and buttons:

- Pallet ID: B0470666 (with a "1 of 3" indicator)
- Job ID: 0303052 (with description: PERUVIAN FALL/HOLIDAY POLY)
- Cust ID: S0146 (with description: SAKS, INC.)
- Part ID: 0001
- Skid #: 26 (with Created: 10/11/2006 @ 11:37:39)
- Sequence: 500 (with Last Trans: 11/15/2006 @ 11:37:39)
- Quantity: 18,527 (with Per Bundle: 0)
- Location: F1B-008-B
- Vendor ID: (empty)
- Description: ??????????
- Hold?
- History

Pallet ID	The Pallet ID.
Job ID	The Job number and description.
Customer ID	The Customer number and name.
Part ID	The Part ID.
Skid #	The Skid number and creation date.
Creation Date	Date the pallet was created.
Sequence	Used to identify the pallet's sequence in production.
Last Trans	Date the pallet was last moved or it's quantity was changed.
Location	The Bay location ID.
Vendor ID	The Vendor number and name.
Description	This is the description of the pallet. It is for reporting purposes.
Hold?	Checking this field will set the status of the pallet to "on hold". Pallets marked as "on hold" will not be identified to the forklift driver as available.
History	Used to generate and view the pallet history report.

Chapter 9 Utilities

Overview


The **P-TRAQ** system contains several programs designed to perform system maintenance, to perform system updates, and to be used when **P-TRAQ** is to communicate with other systems. The following describes these programs in detail.

DataCopy

In some cases when the software is updated, new fields are added, deleted or changed in the **P-TRAQ** database. DataCopy is used to copy tables in the current database to the new tables in the updated database.

DataCopy should be executed on the server and on the whenever the current database structure has been modified. However, when using SQL server, Data Copy is not required to be run on the server.

To execute from the Server, double click the **DataCopy.exe** in the **PTRAQ\Shared** directory.




- To begin the copy process, click the **Continue** button.

DataLoad

Data Load is used to extract and transfer data from the Primac Master Files to the **P-TRAQ** database. The DataLoad download criterion is user defined in the **DataLoad.ini** file located in the **C:\PTRAQ\Shared\Init** directory on the server. The file itself contains a description of each required parameter.

To execute, double click the **DataLoad.exe** in the **C:\PTRAQ\Shared** directory on the server.



To begin the copy process, click the **Continue** button. To expedite the flow of data to and from the server, tables can be copied in real time by clicking the associated **Copy** button.

DataLoad should be left running on the server at all times, however, you may Schedule the task as outlined in the following:

Using Windows “Scheduled Tasks”, you may schedule **DataLoad** to run periodically. The following is the procedure to set up the task:


- Choose **Start – ControlPanel – ScheduledTasks**
- Click “Add Scheduled Task”.
- Click “Next”.
- Click the “*Browse*” button and browse the server to the PTRAQ\Shared directory and select the **DataLoad.exe** file.
- Follow the instructions to select the time and enter the user name and password when prompted.
- Check the box marked “*Open Advanced Properties for this Task when I click Finish*” button and click the finish button.
- In the *Run* field, change the path to read exactly as in the following: **C:\PTRAQ\Shared\DataLoad.exe AUTO**
- In the *Start In* field, make sure the path is as following: **C:\PTRAQ\Shared**

SysUpd

SysUpd is used to copy the latest Programs for the server whenever a system update is performed.

To execute, double click the **SysUpd** icon on the Client Computer's desktop.

To begin the update process, click the **Update** button.



WIP_Security

User Security is used to set the security level or overall access of users of the system. This program is used for two distinct purposes. The first is to record the security level of P-TRAQ client users. The user ID pertains to the Windows user ID and the level dictates the amount of editing control the user has in the P-TRAQ program. The employee field is not accessible in this option. The second purpose of the program is to allow RF users to gain access to the WIP RF menu. In this situation, the user ID is always "RF" and the employee field must be entered with a valid employee ID. This employee ID is supplied by an outside system to the P-TRAQ database. After a valid employee ID is entered, the employee name will display in the name field, as verification of the employee ID. The level field is not used in this situation.

To execute, double click the **WIP_Security.exe** in the **PTRAQ\Shared** directory on the server.

- User ID** For Client software users, enter the Windows logon ID. For RF users, enter RF in this field.
- Employee** The Employee number of the RF user whose security level is to be modified. For Client software users, this field is not accessible.
- Name** The Employee name of the RF user is displayed here for verification purposes.
- Level** Used to select the security level as User, Manager, Admin, or Super User.
- User Level* An employee with User Level access can run reports, use the inquiry options, create and edit pallets.

9 - 12 Chapter 9 Utilities

<i>Manager Level</i>	Manager Level employees can edit racks within a division, print placards and allocate racks to a job in addition to all other User Level Functions.
<i>Admin Level</i>	Admin Level employees can create warehouses within a division in addition to all other Manager Level Functions.
<i>Super User Level</i>	Super User Level employees can perform all system functions across all company-wide divisions.
WIP	This check box is only used for RF users. Check the WIP box if the RF user can access the WIP RF menu.
Shipping	This check box is only used for customers that have a custom addition to P-TRAQ.
Non-Mail	This check box is only used for customers that have a custom addition to P-TRAQ.

Appendix A RF Controllers

While the P-TRAQ system supports most RF controllers on the market, please contact NASTech personnel before purchasing one to ensure compatibility.

Install

- Install as per the manufacturer's instructions.

Connect

- The RF controller is typically connected to your PC using the serial port.

Configure

- The RF controller communicates to the P-TRAQ server computer over Ethernet port 50080.

Troubleshoot

- Ensure that the PC to which the controller is connected has access over the network to the P-TRAQ server computer.
- Ensure that the unit is connected properly to the PC's serial port.